

Part No.	Description	Qty
EC1800-103	Transformer	1
EC1800-108	X Motor	1
EC1800-564	Y Limit Switch	1
FJ1800-254	Spring, Pinchwheel Lift Arm	1
FR2000-512	Ribbon Cable with Plate	1
FJ2000-109	Y Motor (Long Type)	1
FJ2000-123	USB Signal Cable	1
FJ2000-177	Pulley, 15Teeth, 6.35 bore, hub & Flange (A Units)	1
FJ2000-178	Pulley, 30 Teeth, 6.35 mm bore hub & Flange	1
FJ2000-302	Keypad PCB	1
FJ2000-305	Fastjet II Main PCB (High Power Single Y Drive)	1
FR2000-303	Head Drive PCB	1
FR2000-304	Tube & Connector	1
FR2000-306	FFSD Head Connecting Data Cable	1
FR2000-308	Wide Head Replacement	1
FR2000-800	Operation Manual	1
FR2000-801	Maintenance Manual	1
FR2000-850	St Processor PCB	1
FR2000-860	Plastic Protective Cover for 2.2	1
FR2000-890	Single Head Replacement	1
FR2000-891	Twin Head Replacement	1
MSFH/16	Coupling	1
NE1800-105	Fan	1
NE1800-183	Pulley, 30 Teeth, 6 mm bore, hub no flange	1
NE1800-196	Dancer Channel Rear Feed Sprung Stops inc. Channels	2
NE1800-205	Timing Belt 177.5 x 6 mm, 2.5 mm Pitch X & Y Axis	1
NE1800-269	Pinchwheel Complete Assy. Slide Type	2
NE1800-278	Knurled Shafts (Short)	1
NE1800-279	Knurled Shafts (Long)	1
TX1800-110	Feed/Take-Up Motor (125 RPM, 12V)	1
TX1800-112	Power Inlet/Switch/Fuse	1
TX1800-113	Bearing Spacer 6 mm Shaft 0.4 mm	1
TX1800-116	2A Fuse	10
TX1800-123	RS232 Signal Cable	1
TX1800-126	Retainer	1
TX1800-127	Feed Bar Cap Free End	1
TX1800-141	Bearing 13 mm o/d 6 mm i/d 5 mm wide Flanged	1
TX1800-142	Bearing 17 mm o/d 6 mm i/d 6 mm wide	1
TX1800-143	Bearing 17 mm o/d 6 mm i/d 6 mm wide Flanged	1
TX1800-144	Bearing 9 mm o/d 4 mm i/d 4 mm wide	1
TX1800-190	Paper Core, Drive Ends (Flanges)	1
TX1800-191	Dancer Bar	1
TX1800-192	Dancer Bar End Cap	1
TX1800-193	Paper Roll Take-Up/Bar	1
TX1800-195	U' Bracket (Horseshoe no bearings)	1
TX1800-196	Feed Bar Drive Cap	1
TX1800-197	Paper Roll Take-up/ Feed for 86"	1
TX1800-199	Paper Feed Bar 72"	1
TX1800-203	Timing Belt 4500 x 10 mm, 5 mm Pitch (Carriage)	1
TX1800-204	Timing Belt 5200 x 10 mm- 5 mm Pitch (Carriage 86")	1

# Plotter Technology

## Fastjet Refillable Pro Spare Parts List

TX1800-250	Spring, Carriage	1
TX1800-252	Spring, Take-up/Feed Pole End	1
TX1800-271	Pinchwheel - Rubber Wheel inc. Bearings	1
TX1800-555	Carriage Wheel & Bearing	1
TX1800-603	Carriage Slide	1